SEL USB Cables and Converters



Easily adapt and connect USB ports

- Connect an EIA-232 serial port cable to a PC USB port to communicate with SEL relays and other devices.
- Connect a PC to any device with a USB Standard-B or Standard-C communications port.
- Extend a USB cable an additional 16 feet with a USB Standard-A active extension cable.



Cable Options

Cable	Description
SEL-C662-06*	USB Standard-A to EIA-232 9-pin male ¹ (6 ft length)
SEL-C662-15*	USB Standard-A to EIA-232 9-pin male ¹ (15 ft length)
SEL-C497	USB Standard-A to USB Standard-C (10 ft length)
SEL-C664	USB Standard-A to USB Standard-B (6 ft length)
SEL-C668	USB Standard-A active extension (16 ft length)

^{*}These cables include a DTE/DCE switch. A second switch provides 5 Vdc on Pin 1 to power other converters and devices.



Making Electric Power Safer, More Reliable, and More Economical +1.509.332.1890 | info@selinc.com | selinc.com



¹Male/female designation refers to cable termination.